

प्रमुख अभियंता Engineer-in-Chief दिल्ली सरकार

GOVERNMENT OF DELHI

लोक निर्माण विभाग

PUBLIC WORKS DEPARTMENT

कार्यालय प्रगुख अभियंता

O/o THE ENGINEER-IN-CHIEF बारहवीं मंजिल, पुलिस मुख्यालय, इंद्रप्रस्थ एस्टेट, नई दिल्ली,

12th FLOOR, POLICE HEAD QUARTER, I.P. ESTATE, NEW DELHI-110002

Tel. Off.: 011-23490260 Fax No. 23319021

e-mail:pwdhqdelhi@gmail.com

एक करम स्टब्स्ट भी औ

No.E-in-C/PWD/00 / 2021 / 1728

Dt: 22.06.2021

Office Order

It is enjoyed upon all the concerned executive staff of PWD to pay special attention to drainage of rain water from all the vulnerable locations particularly from the underpasses. In rainy season, vulnerable points as well as under passes should be manned round the clock and it should be ensured that all the pumps start immediately. If the depth of the water below underpasses increase more than 20cm., the traffic from both the sides of underpass may be stopped with the help of traffic police to avoid any accident. It will be the responsibility of the concerned Executive Engineer in charge of pumping stations to provide the phone numbers of concerned traffic police officials at pumping stations and should sensitize the staff deployed at the vulnerable points to immediately inform traffic police to stop traffic.

Engineer-in-Chief, PWD

Copy to:

- 1. The Secretary(PWD), GNCTD, Delhi Sachivalaya, I.P Estate, New Delhi.
- 2. The Special Commissioner of Police (Traffic), 3rd floor, Delhi Police Hqrs, Jai Singh Road. New Delhi. It is requested that instructions to stop the traffic in case water rises beyond 20 cm at underpasses, may be issued to field staff of Police Department.
- 3. The Pr. Chief Engineer (Maintenance), PWD, GNCTD, New Delhi for information and necessary action.
- 4. All Chief Engineers under Pr. Chief Engineers (Maintenance), New Delhi for information and necessary action.

5. All the SEs of Maintenance zones of PWD, New Delhi for information and necessary action.

6. Guard File.

Della Ana PWD Webnite Monter ned. Engineer-in-Chief. PWI